

EQUALIZER • CINEMA SURROUND • COMPONENT INPUT

Contents

Knowing your TV's features 3
Remote control buttons and basic functions 4
TV buttons and functions 6
Setting up your TV 7
Basic setting for picture 9
Advanced setting for picture 11
Basic setting for sound 12
Advanced setting for sound 13
Favorite channel and video setting 14
Customized setting 15
TV channel presetting 17
Additional preparation 20
Troubleshooting 21
Specifications ..... Back cover

INSTRUCTIONS

GGT0039-001B-H

5/25/04, 1:21 PM

u for buying this JVC colour television.
e your new TV, please read this manual thoroughly before you begin.

O NOT
ISTURE.
E THE
OF THIS TV.

r of the TV.
nplugging the

e.
nd the TV of

n

echnician. Do

careful with it
led, wipe it
y cleaner or

7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

res

You can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 or NICAM Sound-multiplex system.
You can register up to four favorite channels for quick recall with one press.
TV detects the brightness of your room and automatically adjust the picture brightness to a suitable level for a better eye care.
TV adjusts the volume automatically to the same level for all TV channels to avoid sudden change of the volume when selecting different TV channel.
You can reduce the picture noise when viewing noisy TV programmes or video sources.
You can choose one of three tones of white to match the video source such as movie, sports, etc. Changing WHITE BALANCE affects the appearance of all other colours on the screen.

ctions

n this instruction manual may not be available for your TV.
ow and check the functions that are equipped for your TV's model number. The
ed at the rear of your TV. When you press a button concerned to a function that is
, it does not work and the logo "Ø" appears on the screen. For a function that is
, it is not displayed in the menu.

	AV-29VS14	AV-25VS14 AV-21VS14	AV-21CS14
	○	○	–
	○	–	–
	○	○	–

6/1/04, 11:47 AM

and basic functions

ode.
nction.

volume.

leo terminal number, stereo/bilingual broadcast system
n.
PR list.
display the PR list.
ose a channel, then press the MENU/OK button.
in the PR list. The channels set to favorite channels are

wo digits programme number, press -/--, then press the

nel with one touch.
o register.
n until “RETURN PLUS PROGRAMMED!” appears.
N+ button until “RETURN PLUS CANCELED!” appears.
annel, if you have not set or have cancelled the Return



(continued)

Note
the MENU, he DISPLAY ❽ or choose nenu.
▼ button ❸ to the next page re functions.
–
the MENU/OK ❷ to exit from nu.
–

n this manual,

u)

s.

	Top menu	2nd menu	Location	3rd menu	Location
MENU	INPUT	EXT. INPUT	P.18	–	–
		DISPLAY	P.18	–	–
	PICTURE * If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER.	PICTURE MODE	P.9	–	–
		PICTURE SETTING	P.10	–	–
		WHITE BALANCE	P.10	–	–
		PICTURE FEATURES	–	VNR	P.15
				FAVORITE CH SETTING	P.14
				VIDEO SETTING	P.14
				COLOUR SYSTEM	P.9
				COMPRESS (16:9)	P.11
				PICTURE TILT	P.11
	SOUND * If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER.	STEREO/I•II	P.15	–	–
		AI VOLUME	P.15	–	–
		SOUND MODE	P.14	–	–
		EQUALIZER	P.15	–	–
		BALANCE	P.14	–	–
		SOUND TURBO	P.14	–	–
		CINEMA SURROUND	P.15	–	–
	FEATURES	OFF TIMER	P.17	–	–
		CHILD LOCK	P.17	–	–
		AI ECO SENSOR	P.11	–	–
	INSTALL	AUTO PROGRAM	P.19	–	–
		EDIT/MANUAL	P.19	DELETE, MOVE, MANUAL,INSERT	P.17-P.18
		LANGUAGE	P.17	LANGUAGE	P.15
		BLUE BACK	P.11	–	–
		AUTO SHUTOFF	P.18	–	–
		VIDEO-2 SETTING	P.18	–	–
		AI ECO DISPLAY	P.11	–	–
	EXIT	–	–	–	–

5/25/04, 1:21 PM

s

AV-21CS14 only, which are used for explanation purpose.

No.	Button/terminal	Description	Page
❶	⏻ (main power)	Press to turn on or turn off the TV's main power.	–
❷	POWER lamp	Indicate the TV is being turned on or off. No colour : TV's main power is being turned off. Red : TV's main power is being turned on. Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds.	–
❸	ECO sensor		–
❹	Remote control sensor		–
❺	TV/ VIDEO	Press to select TV or video mode.	–
❻	VOLUME -/+	Press to adjust the volume level.	–
❼	CHANNEL -/+	Press to select the desired channel.	–
❽	MENU	Press to display the menu.	–
❾	IN (VIDEO-3)	Video and audio input jacks for VIDEO-3 mode.	20
	IN (VIDEO-2)	Video and audio input jacks for VIDEO-2 mode.	20
❿	🎧	Headphone jack.	20
⓫	⊤	Aerial socket.	7
⓬	OUTPUT	Video and audio output jacks. (The component video signal cannot be output.)	20
⓭	COMPONENT (VIDEO-2) INPUT	Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 16).	20
⓮	VIDEO-1 INPUT	Video or S-VIDEO, and audio input jacks for VIDEO-1 mode	7

How to operate the menus with the TV button

TV button	Work as same as the button on the remote control unit	Note
MENU	MENU/OK button	To display main menu and exit menu after finish setting.
CHANNEL -/+	▼/▲ button	To select menu function.
VOLUME -/+	◄/► button	To adjust the desired function.

nnecting.

or aerial

upplied)

your VCR
connect the
of the TV
d audio

r aerial

me as your

2 Connecting the compatible main plug to the AC outlet.



3 Inserting batteries into the remote control.

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

CAUTION:

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- It the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



4 Turn on the TV by pressing the main power button.

JVC logo appears on the screen.

5/25/04, 1:21 PM

button, then operate the TV menu by following the steps as below:



searching
nels.

TO
, press
utton.

- Press the red button to cancel the SETUP TOUR RESTART function.
  If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.



- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 17.

d AUTO PROGRAM functions to make the initial settings. Those functions are

nitial settings, press the TV/VIDEO button to exit from initial settings.

PICTURE MODE

You can choose the desired picture setting with one-touch.
Press the PICTURE MODE button to select a setting.

SOFT	Softens contrast and sharpness.
BRIGHT	Heightens contrast and sharpness.
STANDARD	Standard picture setting.
USER	You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*)

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

e picture is

g.

ES menu)

he table

	System
es, tc.	PAL
	PAL
	PAL
tc.	SECAM
	NTSC
	SECAM
	PAL
	PAL
	PAL
	PAL
	PAL
	PAL
	SECAM

5/25/04, 1:21 PM

ting USER

URE menu.
ODE)

, then adjust

TTING)

ntrast

WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.

✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

NORMAL	Normal white balance.
COOL	Bluish white.
WARM	Reddish white.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

ture

rightness of

OR)

he screen.
en choose

RE TILT)

agnetic force.
RES menu
on.
TURES menu)

2 Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.

✳(MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COMPRESS (16:9))

BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.

✳(MENU) ➔ (INSTALL menu) ➔ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 3:33 PM

onormal
y.
.

he table

	System
es, tc.	B/G
	D/K
	I
tc.	B/G
	M
	D/K
	D/K
	B/G
	I
	B/G
	I
	B/G
	B/G

SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE)

USER	You can change this sound setting as you like. Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz). For details, see “EQUALIZER” on page 13.
DYNAMIC	Emphasize on both vocal sound and music.
MUSIC	Emphasize on music effect.
NEWS	Emphasize on vocal sound.

BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (BALANCE)

SOUND TURBO

You can set the sound frequency to emphasize the low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

EQUALIZER

You can adjust the sound frequencies when selecting USER mode in SOUND MODE.

1 Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

2 Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.



3 Select and adjust the desired frequencies.

4 Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.

Select the AI VOLUME in SOUND menu, then choose ON or OFF.

✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 3:33 PM

eo setting

ng the

ed to register.
ore.
ars on the

o 2.

ion is not

rite channels.
CH

TURES menu

ETTING

EL)



4 Select the desired item that you wish to adjust.

CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

1 Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VIDEO SETTING)

2 Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.

✳ (VIDEO SETTING) ➔ (VIDEO STATUS)

3 Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.



4 Select the desired item that you wish to adjust.

CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

✳ (MENU) ➡ (FEATURES menu) ➡ (CHILD LOCK)

OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.



You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

✳ (MENU) ➡ (FEATURES menu) ➡ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 3:33 PM

EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➔ (INPUT menu) ➔ (EXT. INPUT)

DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST

Choose a TV channel or a VIDEO terminal.

1 Press the DISPLAY button to display the PR LIST.

2 Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.



To operate this function with a menu:

✳ (MENU) ➔ (INPUT menu) ➔ (DISPLAY)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

cally

el list

OK button.
ls received
cally.

n proceed to
page 8.

the channel

ter the
ge.

list manually.

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.



3 Choose the channel which you want to register.

4 Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

5 Press the ► button to choose an appropriate sound system.
For details, see “SOUND SYSTEM” on page 12.

6 Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

7 Repeat step 5 until your desired TV channel appears

If the reception is poor	Press the blue or yellow button to fine tune the TV channel.
If noisy sound is heard	Press the ► button to choose an appropriate sound system.

8 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 3:33 PM

)

rs will be

button.

number, or

to the PR
channel.

To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like. You need to find the “CH/CC” number for the TV channel. Find the “CH/CC” number corresponding to the channel number of the TV channel from the attached sheet “CH/CC number list” on page 19.

1 Display the INSTALL menu.
✳ (MENU) ➡ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

3 Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

4 Press the green button, then press ▲/▼ buttons to choose “CC” or “CH”.

5 Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

US	CCIR	OIRT	AUSTRALIA
US-33, W+48	E33		
US-34, W+49	E34		
US-35, W+50	E35		
US-36, W+51	E36		
US-37, W+52	E37		
US-38, W+53	E38		
US-39, W+54	E39		
US-40, W+55	E40		
US-41, W+56	E41		
US-42, W+57	E42		
US-43, W+58	E43		
US-44, W+59	E44		
US-45, W+60	E45		
US-46, W+61	E46		
US-47, W+62	E47		
US-48, W+63	E48		
US-49, W+64	E49		
US-50, W+65	E50		
US-51, W+66	E51		
US-52, W+67	E52		
US-53, W+68	E53		
US-54, W+69	E54		
US-55, W+70	E55		
US-56, W+71	E56		
US-57, W+72	E57		
US-58, W+73	E58		
US-59, W+74	E59		
US-60, W+75	E60		
US-61, W+76	E61		
US-62, W+77	E62		
US-63, W+78	E63		
US-64, W+79	E64		
US-65, W+80	E65		
US-66, W+81	E66		
US-67, W+82	E67		
US-68, W+83	E68		
US-69, W+84	E69		

US	CCIR	OIRT	AUSTRALIA
	S-1		AU-5
	S-2		
	S-3		
	S-4		
	S-5		
	S-6		AU-5A
	S-7		
	S-8		
	S-9		
	S-10		
	S-11		
	S-12		
	S-13		
A	S-14		
B	S-15		
C	S-16		
D	S-17		

CC	US	CCIR	OIRT	AUSTRALIA
CC 18	E	S-18		
CC 19	F	S-19		
CC 20	G	S-20		
CC 21	H	S-21		
CC 22	I	S-22		
CC 23	J	S-23		
CC 24	K	S-24		
CC 25	L	S-25		
CC 26	M	S-26		
CC 27	N	S-27		
CC 28	O	S-28		
CC 29	P	S-29		
CC 30	Q	S-30		
CC 31	R	S-31		
CC 32	S	S-32		
CC 33	T	S-33		
CC 34	U	S-34		
CC 35	V	S-35		
CC 36	W	S-36		
CC 37	W+1	S-37		
CC 38	W+2	S-38		
CC 39	W+3	S-39		
CC 40	W+4	S-40		
CC 41	W+5	S-41		
CC 42	W+6			
CC 43	W+7			
CC 44	W+8			
CC 45	W+9			
CC 46	W+10			
CC 47	W+11			
CC 48	W+12			
CC 49	W+13			
CC 50	W+14			
CC 51	W+15			
CC 52	W+16			
CC 53	W+17			
CC 54	W+18			
CC 55	W+19			
CC 56	W+20			
CC 57	W+21			
CC 58	W+22			
CC 59	W+23			
CC 60	W+24			
CC 61	W+25			
CC 62	W+26			
CC 63	W+27			
CC 64	W+28			
CC 75		X		
CC 76		Y	R3	
CC 77		Z	R4	AU-3
CC 78		Z+1	R5	
CC 79		Z+2		AU-4
CC 95	A-5			
CC 96	A-4			
CC 97	A-3			
CC 98	A-2			
CC 99	A-1			

6/8/04, 3:33 PM

S14 and
ose. Your

e proper

nal

or TV game

Connecting to rear component/video input terminal and output terminal

Rear of TV

AV-29VS14



VCR (for playing)
DVD player (composite signals)

VCR (for recording)

DVD player
(component video signals)

Rear of TV

AV-21CS14



VCR (for playing)

VCR (for recording)

When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture displays on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 16).

• Cannot operate the remote control	• The batteries may be exhausted. Replace with new batteries (see page 7). • Ensure that you are operating the remote less than seven meters from the front of your TV.
• Cannot operate the menus	• Press TV/VIDEO button to return to TV mode and try operating the menus.
• Cannot operate the front control buttons	• Deactivate the CHILD LOCK function if it is turned on (see page 15).
• TV is turned off suddenly	• This may due to the AUTO SHUT OFF function is activated. Press the POWER button to turn on the TV.
• Colour patches appear at the corner of the screen	• This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker.
• Picture is tilted	• This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt.
• Image takes a short period to be displayed	• Image required time to stabilize before display. This is not a malfunction.
• TV may emitted crackling sound	• This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection.
• Feel a slight electric shock when touching the TV screen	• This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction.

5/25/04, 1:22 PM

Hz

), UHF channel (U)
and and hyper band.

ect for AV-21CS14), VIDEO input, AUDIO L/R input
O L/R input, COMPONENT VIDEO ($Y/C_B/C_R$) input (Except for AV-21CS14)
O L/R input (Except for AV-21CS14)
DIO L/R output
.5 mm diameter)

out notice.

JVC
VICTOR COMPANY OF JAPAN, LIMITED

0604-FLE-JMT

5/25/04, 1:22 PM

JVC

COLOUR TELEVISION

EQUALIZER • CINEMA SURROUND • COMPONENT INPUT

AV-29LS24
AV-29LX14
AV-29VS24
AV-29VX54
AV-29VX74
AV-29WX14
AV-29WX24
AV-25LS24
AV-25LX14
AV-25VS24
AV-25VX54
AV-25VX74
AV-21CS24
AV-21CX14
AV-21DX14
AV-21LX14
AV-21VS24
AV-21VX14
AV-21VX54
AV-21VX74
AV-21WS24
AV-21WX14
AV-21YX14

Contents

Knowing your TV's features 3
Remote control buttons and basic functions 4
TV buttons and functions 6
Setting up your TV 7
Basic setting for picture 9
Advanced setting for picture 11
Original features for picture 12
Basic setting for sound 14
Advanced setting for sound 15
Favorite channel and video setting 16
Customized setting 17
TV channel presetting 19
Additional preparation 22
Troubleshooting 23
Specifications ..... Back cover

INSTRUCTIONS

GGT0045-001C-H

Thank you for buying this JVC colour television.
To make sure you understand how to use your new TV, please read this manual thoroughly before you begin.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION: TO ENSURE PERSONAL SAFETY, OBSERVE THE FOLLOWING RULES REGARDING THE USE OF THIS TV.

1 Operate only from the power source indicated on the rear of the TV.
2 Avoid damaging the power cord and mains plug. When unplugging the TV, grasp the mains plug. Do not pull on the power cord.
3 Never block or cover the ventilation openings.
Never install the TV where good ventilation is unattainable.
When installing this TV, leave spaces for ventilation around the TV of more than the minimum distances as shown.



4 Do not allow objects or liquid into the cabinet openings.
5 In the event of a fault, unplug the unit and call a service technician. Do not attempt to repair it yourself or remove the rear cover.
6 The surface of the TV screen is easily damaged. Be very careful with it when handling the TV. Should the TV screen become soiled, wipe it with a soft dry cloth. Never rub it forcefully. Never use any cleaner or detergent on it.
7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

WARNING: <AV-21WS24/AV-21WX14/AV-21YX14 only>
A REMOVABLE PLASTIC COVER IS FIXED TO THE TELEVISION'S FRONT AUDIO/VIDEO CONNECTOR. TO PREVENT THIS COVER FROM BEING ACCIDENTALLY SWALLOWED BY BABIES OR CHILDREN, REMOVE IT FROM THE TELEVISION AND STORE IT IN A SAFE PLACE. IF THE COVER IS SWALLOWED SEEK THE ADVICE OF A DOCTOR IMMEDIATELY.

Knowing your TV's features



Main features

PIP (Picture in Picture)	You can view two different sources (e.g. TV programme and VCR sources) at the same time.
TELETEXT	You can view teletext programmes which are broadcasted by some TV channels. Teletext programme is an information in text form.
A2/NICAM (STEREO / I•II)	You can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 or NICAM Sound-multiplex system.
FAVORITE CH (Channel)	You can register up to four favorite channels for quick recall with one press.
AI ECO	TV detects the brightness of your room and automatically adjust the picture brightness to a suitable level for a better eye care.
AI VOLUME	TV adjusts the volume automatically to the same level for all TV channels to avoid sudden change of the volume when selecting different TV channel.

Confirm your TV's functions

Some functions written in this instruction manual may not be available for your TV.
Please see the chart below and check the functions that are equipped for your TV's model number. The model number is indicated at the rear of your TV. When you press a button concerned to a function that is not available for your TV, it does not work and the logo "Ø" appears on the screen. For a function that is not available for your TV, it is not displayed in the menu.

No.	Model No. / Function	AV-29LX14	AV-29WX14	AV-25LX14 AV-21LX14	AV-21VX14 AV-21WX14	AV-29VX54	AV-25VX54 AV-21VX54	AV-29WX24	AV-29LS24	AV-29VS24	AV-25LS24	AV-21CS24	AV-25VS24 AV-21WS24 AV-21VS24	AV-29VX74	AV-25VX74 AV-21VX74	AV-21CX14	AV-21DX14	AV-21YX14
❶	I/II (STEREO/I•II)	–	–	–	–	–	–	–	○	○	○	○	○	–	–	–	–	–
❷	*PICTURE BOOSTER	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○
❸	*ECO	–	○	–	○	○	○	○	–	○	–	–	○	○	○	–	–	–
❹,❻	PIP control buttons (Green label)	–	–	–	–	○	○	–	–	–	–	–	–	○	○	–	–	–
❺,❻	TELETEXT control buttons (Black label)	–	–	–	–	–	–	○	○	○	○	○	○	○	○	–	–	–
–	PICTURE TILT	○	○	–	–	○	–	○	○	○	–	–	–	○	–	–	–	–
–	COMPRESS (16:9)	○	○	○	○	○	○	○	○	○	○	–	○	○	○	–	○	–

Remote control buttons and basic functions

No.	Press	To
❶	POWER	Turn on or off the TV from standby mode.
❷	MENU/OK	Display menu and confirm selected function.
❸	▲ / ▼ / ◄ / ►	Select and adjust menu function.
❹	CHANNEL -/+	Select the desired channel number.
❺	VOLUME -/+	Adjust the volume level.
❻	TV/VIDEO	Select TV or video terminal input.
❼	MUTING	Turn off the volume. Press this button again to resume the volume.
❽	DISPLAY	Display the programme number or video terminal number, stereo/bilingual broadcast system and PR list (channel list) on the screen. You can select the channel using the PR list. **1** Press the DISPLAY button once to display the PR list. **2** Press ▲ / ▼ / ◄ / ► buttons to choose a channel, then press the MENU/OK button. You can confirm the favorite channels in the PR list. The channels set to favorite channels are indicated with coloured mark.
❾	0~9, -/--	Select the programme number. For two digits programme number, press -/--, then press the number button.
❿	RETURN+	a) Return to the frequently view channel with one touch. **1** Choose the channel you want to register. **2** Press and hold RETURN+ button until “RETURN PLUS PROGRAMMED!” appears. To cancel, press and hold RETURN+ button until “RETURN PLUS CANCELED!” appears. b) Return to the previously viewed channel, if you have not set or have cancelled the Return channel as above.



Remote control buttons and basic functions (continued)

How to operate menus and menus locations

To	Operation	Note
Display the MENU	Press the MENU/OK button ❷.	To exit the MENU, press the DISPLAY button ❽ or choose EXIT menu.
Display the top menu	Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷.	Press ▼ button ❸ to display the next page for more functions.
Display the 2nd menu	Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷.	
Display the 3rd menu	Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷.	
Return to the previous menu	Press the DISPLAY button ❽.	–
Choose the setting of a function	Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to change the setting.	Press the MENU/OK button ❷ to exit from the menu.
Adjust the effect level of a function	Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to adjust the effect level.	
Display the sub menu of a function.	Press the ▲/▼ buttons ❸ to choose a function. Then press MENU/OK button ❷ to display the sub menu.	–

The following chart shows locations of functions in menus. In this manual, location of a function is described as follows:

(MENU) ➔ (Top menu) ➔ (2nd menu)

(MENU) ➔ (Top menu) ➔ (2nd menu) ➔ (3rd menu)

Note: Some functions have the 4th menus as the sub-menus.

	Top menu	2nd menu	Location	3rd menu	Location
MENU	INPUT	EXT. INPUT	P.18	–	–
		DISPLAY	P.18	–	–
	PICTURE * If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER.	PICTURE MODE	P.9	–	–
		PICTURE SETTING	P.10	–	–
		WHITE BALANCE	P.10	–	–
		PICTURE FEATURES	–	VNR	P.17
				FAVORITE CH SETTING	P.16
				VIDEO SETTING	P.16
				COLOUR SYSTEM	P.9
				PICTURE BOOSTER	P.10
				COMPRESS (16:9)	P.11
				PICTURE TILT	P.11
	SOUND * If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER.	STEREO/I•II	P.15	–	–
		AI VOLUME	P.15	–	–
		SOUND MODE	P.14	–	–
		EQUALIZER	P.15	–	–
		BALANCE	P.14	–	–
		SOUND TURBO	P.14	–	–
		CINEMA SURROUND	P.15	–	–
	FEATURES	OFF TIMER	P.17	–	–
		CHILD LOCK	P.17	–	–
		AI ECO SENSOR	P.11	–	–
		PIP	–	PIP,SUB INPUT,SWAP	P.12
	INSTALL	AUTO PROGRAM	P.19	–	–
		EDIT/MANUAL	P.19	DELETE, MOVE, MANUAL, INSERT	P.19-P.20
		LANGUAGE	P.17	LANGUAGE	P.17
		BLUE BACK	P.11	–	–
		AUTO SHUTOFF	P.18	–	–
		VIDEO-2 SETTING	P.18	–	–
		AI ECO DISPLAY	P.11	–	–
		TEXT LANGUAGE	P.13	TEXT LANGUAGE	P.13
	EXIT	–	–	–	–

TV buttons and functions

The illustrations shown below is for AV-29VS24 and AV-21CS24 only, which are used for explanation purpose.
Your TV may not look exactly the same as illustrated.

Front of the TV

AV-29VS24



AV-21CS24



Rear of the TV

AV-29VS24



AV-21CS24



No.	Button/terminal	Description	Page
❶	⏻ (main power)	Press to turn on or turn off the TV's main power.	–
❷	POWER lamp	Indicate the TV is being turned on or off. No colour : TV's main power is being turned off. Red : TV's main power is being turned on. Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds.	–
❸	ECO sensor		–
❹	Remote control sensor		–
❺	TV/VIDEO	Press to select TV or video mode.	–
❻	VOLUME -/+	Press to adjust the volume level.	–
❼	CHANNEL -/+	Press to select the desired channel.	–
❽	MENU	Press to display the menu.	–
❾	IN (VIDEO-3)	Video and audio input jacks for VIDEO-3 mode.	22
	IN (VIDEO-2)	Video and audio input jacks for VIDEO-2 mode.	22
❿	🎧	Headphone jack.	22
⓫	⊤	Aerial socket.	7
⓬	OUTPUT	Video and audio output jacks. (The component video signal cannot be output.)	22
⓭	COMPONENT (VIDEO-2) INPUT	Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 18).	22
⓮	VIDEO-1 INPUT	Video or S-VIDEO, and audio input jacks for VIDEO-1 mode	7

How to operate the menus with the TV button

TV button	Work as same as the button on the remote control unit	Note
MENU	MENU/OK button	To display main menu and exit menu after finish setting.
CHANNEL -/+	▼/▲ button	To select menu function.
VOLUME -/+	◄/► button	To adjust the desired function.

Setting up your TV

CAUTION

- Turn off the equipment including the TV before connecting.

1 Connecting the aerial cable.



If you connect a VCR, connect the aerial output jack of your VCR and the aerial jack on the TV with aerial cable. Then connect the output jacks of your VCR and the VIDEO-1 input jacks of the TV with the video cable (or S-VIDEO cable if available) and audio cables. For details, see the manual of your VCR.



The illustration shown is just a sample. It may not be same as your TV.

2 Connecting the compatible main plug to the AC outlet.



3 Inserting batteries into the remote control.

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

CAUTION:

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- If the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



4 Turn on the TV by pressing the main power button.

JVC logo appears on the screen.

Setting up your TV (continued)

5 Making the initial settings

Set up your TV by pressing any button except POWER button, then operate the TV menu by following the steps as below:



- Press ▲/▼ button to select your desired language*, then press MENU/OK button.
- Press ▲/▼ button to select your desired Teletext language group*. For details, see page 13. (For CS24/LS24/ VS24/VX74/WS24/ WX24 series only)
- TV will start searching for the channels.

  To stop AUTO PROGRAM, press MENU/OK button.
- Press the red button to cancel the SETUP TOUR RESTART function. If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.
- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 19.

If the JVC logo does not appear, use LANGUAGE, TEXT LANGUAGE, and AUTO PROGRAM functions to make the initial settings. Those functions are located in the INSTALL menu.

If the JVC logo appears, although you had made the initial settings, press the TV/VIDEO button to exit from initial settings.

* If the TEXT function is available for your TV and the LANGUAGE shown follow as ENGLISH/РУССКИЙ/ عربي / فارسغ ی /FRANÇAIS, you can select the TEXT LANGUAGE group from GROUP-1 to GROUP-4.
If the TEXT function is available for your TV and the LANGUAGE shown follow as ENGLISH/РУССКИЙ/ 中 文/MELAYU/INDONESIA, you can select the TEXT LANGUAGE group from GROUP-1 to GROUP-3.

Basic setting for picture

COLOUR SYSTEM

You can select the appropriate colour system when the picture is not clear or no colour appears.
Press the COLOUR SYSTEM button to select a setting.

AUTO → PAL → SECAM → NTSC3.58
NTSC4.43 ←

To operate this function with a menu:
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COLOUR SYSTEM)

For the colour system in each country or region, see the table below:

Area	Country or Region	System
Asia, Middle East	Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc. Indonesia, Malaysia, Singapore, Thailand, India, etc.	PAL
	China, Vietnam, etc.	PAL
	Hong Kong, etc.	PAL
	Islamic Republic of Iran, Lebanon, Saudi Arabia, etc.	SECAM
	Philippines, Taiwan, Myanmar, etc.	NTSC
Europe	Russia, etc.	SECAM
	Czech Republic, Poland, etc.	PAL
	Germany, Holland, Belgium, etc.	PAL
	UK, etc.	PAL
Oceania	Australia, New Zealand, etc.	PAL
Africa	Republic of South Africa, etc.	PAL
	Nigeria, etc.	PAL
	Egypt, Morocco, etc.	SECAM

PICTURE MODE

You can choose the desired picture setting with one-touch.
Press the PICTURE MODE button to select a setting.

SOFT	Softens contrast and sharpness.
BRIGHT	Heightens contrast and sharpness.
STANDARD	Standard picture setting.
USER	You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*)

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Adjusting the picture – USER

You can adjust the desired picture setting when selecting USER in PICTURE MODE.

1 Select the USER in PICTURE MODE under PICTURE menu.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE) ➔ (USER)

2 Select the PICTURE SETTING in PICTURE menu, then adjust the setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE SETTING)

CONTRAST	◄ : Lower contrast	► : Higher contrast
BRIGHT	◄ : Darker	► : Brighter
SHARP	◄ : Softer	► : Higher
COLOUR	◄ : Lighter	► : Deeper
TINT*	◄ : Reddish	► : Greenish

*TINT can only be adjusted in NTSC system.

PICTURE BOOSTER

You can improve picture clarity when the picture is unclear due to the low signal reception.
Press the PICTURE BOOSTER button to select the desired mode.

HIGH	Perform at maximum level.
LOW	Perform at minimum level.
OFF	Cancel the function

To operate this function with a menu:
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE BOOSTER)

WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

NORMAL	Normal white balance.
COOL	Bluish white.
WARM	Reddish white.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Advanced setting for picture

AI ECO SENSOR (ECO)

You can adjust TV screen contrast according to the brightness of your room.
Press the ECO button to select the desired mode.

1	Mild contrast (recommended).
2	Even contrast.
OFF	Cancel the function.

To operate this function with a menu:
✳ (MENU) ➔ (FEATURES menu) ➔ (AI ECO SENSOR)

You can display the graphic of AI ECO SENSOR on the screen.
Select the AI ECO DISPLAY in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (AI ECO DISPLAY)

Correcting the Slanting Picture (PICTURE TILT)

You can correct the picture tilt caused by the earth's magnetic force.

1 Select the PICTURE TILT in the PICTURE FEATURES menu under PICTURE menu, then press MENU/OK button.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE TILT)
The following display appears.



2 Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COMPRESS (16:9))

BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

Original features for picture

PIP

You can display a sub picture on the screen.
Press the PIP operation buttons to display and change the sub picture setting.

PIP	Display the sub picture. To cancel, press the PIP button again. **Notes:** • You can hear the sound from the main picture only. • Main picture and sub picture will use different input sources, which are TV and VIDEO mode. When the same input source are selected, the sub picture input source will change as follows: Main picture / Sub picture TV / VIDEO-1 → VIDEO-2 → VIDEO-3 VIDEO-1 / TV → VIDEO-2 → VIDEO-3 VIDEO-2 / TV → VIDEO-1 → VIDEO-3 VIDEO-3 / TV → VIDEO-1 → VIDEO-2
SUB-P -/+	Select the desired channel for sub picture.
(Input)	Select the input source for the sub picture.
(Swap)	Swap between the main picture and sub picture.
(Position)	Change the sub picture position. Each time you press on (Position) button, the sub picture position will change as follows: lower right → lower left → upper left → upper right → lower right
(Freeze)	Freeze the sub picture to be still.

To operate this function with a menu:
✳ (MENU) ➔ (FEATURES menu) ➔ (PIP)

When VIDEO-2 is set to component, you can't select VIDEO-2 for sub picture.

When VIDEO-2 is set to component, if the input source of main picture is set to VIDEO-2 with component, PIP button is disabled and sub picture can't be displayed.

TELETEXT

You can watch the Teletext broadcast channel with TEXT function.

1 Press the TEXT button to select the desired mode as follows:

TV mode → TEXT mode → MIX mode → TV mode

2 Press the CHANNEL -/+ buttons, number buttons or colour buttons to select other Teletext pages.

3 Press TEXT or TV/VIDEO button to return to TV mode.

You can also operate the teletext using the following buttons:

(Hold)	Hold a teletext page. The (Hold) are displayed at the top left of the screen. To cancel, press (Hold) button again.
(Reveal)	Display the hidden text (e.g. answers to a quiz). To cancel, press (Reveal) button again.
(Size)	Enlarge the teletext display.
(Index)	Return to the index page instantly.
(Cancel)	Watch TV programme while waiting for a teletext page. When the teletext page is found, a page number appears at the upper left of the screen. Press (Cancel) to view the teletext page.
(Sub-page)	Operate the (Sub-page) function. Sub-page numbers are displayed at the left of the screen. To cancel sub-page function, press (Sub-page) button again.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

Original features for picture (continued)

Using the List mode

You can store and recall the favorite teletext pages in memory using the colour buttons.

1 In TEXT mode, press the MODE button to enter the List mode.

2 Press a colour button, then press the number buttons to enter the page number.

3 Press and hold down the ◇ (Store) button.
The page number is blinking white to indicate that they are stored in memory.

4 To store other favorite teletext pages, repeat Step 2 to 3.

To recall the favorite teletext page, press the MODE button, then press the colour button.
To exit the List mode, press the MODE button again.
When viewing teletext programme, menu operations are not available.
If characters on a teletext programme do not appear properly, change the TEXT LANGUAGE setting.

TEXT LANGUAGE

You can set the Teletext language group that corresponds to the programmes.
Select TEXT LANGUAGE in the INSTALL menu, then choose the desired language group.

✳ (MENU) ➔ (INSTALL menu) ➔ (TEXT LANGUAGE)

GROUP-1	English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish
GROUP-2	Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian
GROUP-3	Polish, German, Estonian, Lettish, Russian, Ukrainian
GROUP-4	English, French, Turkish, Arabic, Iranian

Depending on the broadcast, the language set may not display properly. For details, see in page 8.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Basic setting for sound

SOUND SYSTEM

You can select an appropriate sound system when abnormal sound occurs even when the picture appears normally.
Press the SOUND SYSTEM button to select a setting.

→ B/G → I → D/K → M

This function is not available in video mode.
For the sound system in each country or region, see the table below:

Area	Country or Region	System
Asia, Middle East	Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc. Indonesia, Malaysia, Singapore, Thailand, India, etc.	B/G
	China, Vietnam, etc.	D/K
	Hong Kong, etc.	I
	Islamic Republic of Iran, Lebanon, Saudi Arabia, etc.	B/G
	Philippines, Taiwan, Myanmar, etc.	M
Europe	Russia, etc.	D/K
	Czech Republic, Poland, etc.	D/K
	Germany, Holland, Belgium, etc.	B/G
	UK, etc.	I
Oceania	Australia, New Zealand, etc.	B/G
Africa	Republic of South Africa, etc.	I
	Nigeria, etc.	B/G
	Egypt, Morocco, etc.	B/G

SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE)

USER	You can change this sound setting as you like. Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz). For details, see “EQUALIZER” on page 15.
DYNAMIC	Emphasize on both vocal sound and music.
MUSIC	Emphasize on music effect.
NEWS	Emphasize on vocal sound.

BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (BALANCE)

SOUND TURBO

You can set the sound frequency to emphasize the low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Advanced setting for sound

CINEMA SURROUND

You can enjoy an enhanced sound for wider audience.
Press the CINEMA SURROUND button to select a setting.

OFF	Cancel the function.
LOW	Listen to sound with less wider audience effect.
HIGH	Listen to sound with more wider audience effect.
MONO	Listen to mono sound with stereo effect.

To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (CINEMA SURROUND)

If slight volume distortion occurs when you select HIGH mode, change the setting to LOW mode. The CINEMA SURROUND effect will be less noticeable.
If you use CINEMA SURROUND and SOUND TURBO together, volume distortion might occurs.

STEREO / I·II (I/II)

You can enjoy the stereo and bilingual broadcasted programmes.
Press the I/II button to select the desired mode.

	Select stereo sound.
	Select monaural sound.
I	Select bilingual I (sub I).
II	Select bilingual II (sub II).
MONO	Cancels the Multi Sound function, and the sound becomes monaural.

This function is not available in video mode.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (STEREO / I·II)

EQUALIZER

You can adjust the sound frequencies when selecting USER mode in SOUND MODE.

1 Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

2 Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.



3 Select and adjust the desired frequencies.

4 Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.
Select the AI VOLUME in SOUND menu, then choose ON or OFF.

✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Favorite channel and video setting

To register the favorite channel

You can register and recall 4 favorite channels by using the colour buttons (red, green, yellow, blue).

1 In TV mode, select a TV channel (PR01-99) you desired to register.

2 Press and hold a colour button for 3 seconds or more.
"FAVORITE CHANNEL ■ PROGRAMMED" appears on the screen and current channel is registered.

3 To register other favorite channels, repeat Step 1 to 2.

To recall the favorite channel, press the colour button.
When the TV is in Text mode, Picture in Picture or menu mode, favorite channel function is not available.

To adjust favorite channel setting (FAVORITE CH SETTING)

You can adjust the picture and sound settings for the favorite channels.

1 Display the PICTURE menu and select FAVORITE CH SETTING in PICTURE FEATURES menu.
✳(MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (FAVORITE CH SETTING)

2 Select FAVORITE CHANNEL in FAVORITE CH SETTING menu, then choose the desired favorite channel.
✳(FAVORITE CH SETTING) ➔ (FAVORITE CHANNEL)

3 Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.



4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

1 Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.
✳(MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VIDEO SETTING)

2 Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.
✳(VIDEO SETTING) ➔ (VIDEO STATUS)

3 Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.



4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

Customized setting

VNR

You can reduce the noise.
Select the VNR in the PICTURE FEATURES menu under PICTURE menu, then choose a setting of VNR function.

* (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VNR)

OFF	VNR is turned off.
AUTO	Effect of VNR is automatically controlled.
MIN	Effect of VNR becomes minimum level.
MAX	Effect of VNR becomes maximum level.

If you select MAX, the picture becomes softer even if the original picture is sharp.

LANGUAGE

You can choose your desired on screen display language.
Select the LANGUAGE in the INSTALL menu, then choose a language.

* (MENU) ➔ (INSTALL menu) ➔ (LANGUAGE)

CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

* (MENU) ➔ (FEATURES menu) ➔ (CHILD LOCK)

OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.



You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

* (MENU) ➔ (FEATURES menu) ➔ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

* About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

Customized setting (continued)

AUTO SHUTOFF

You can set the TV to turn off automatically when no signal is received for about 15 minutes or longer after the end of a broadcast.
Select AUTO SHUTOFF in INSTALL menu, then choose ON or OFF.

✳ (MENU) ➔ (INSTALL menu) ➔ (AUTO SHUTOFF)

The AUTO SHUTOFF function does not turn off the TV's main power.
The AUTO SHUTOFF function is not available in video mode.

VIDEO-2 SETTING

You can set the VIDEO-2 SETTING according to the video signal output from the external devices connected to the VIDEO-2 terminal.
Select the VIDEO-2 SETTING in INSTALL menu, then choose a setting.

✳ (MENU) ➔ (INSTALL menu) ➔ (VIDEO-2 SETTING)

VIDEO	If a normal video signal (composite video signal) is input.
COMPONENT	If a component video signal ($Y/C_B/C_R$) is input.

For connecting methods, see "Additional Preparation" on page 22.

EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➔ (INPUT menu) ➔ (EXT. INPUT)

DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST

Choose a TV channel or a VIDEO terminal.

1 Press the DISPLAY button to display the PR LIST.

2 Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.



To operate this function with a menu:

✳ (MENU) ➔ (INPUT menu) ➔ (DISPLAY)

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

TV channel presetting

To register the TV channels automatically

You can register the TV channels into the TV's channel list automatically.

1 Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

2 Choose AUTO PROGRAM, then press the MENU/OK button. AUTO PROGRAM function starts, and the channels received are registered in the channel list (PR LIST) automatically.

3 "SETUP TOUR RESTART?" appears.

To start the SETUP TOUR	Press the MENU/OK button. Then proceed to step 5 of "Setting up your TV" on page 8.
To skip the SETUP TOUR	Press the Red button.

4 The EDIT menu appears.

To edit the channel list	Proceed to the Step 3 of "To edit the channel list (PR LIST)" on page 20.
If a channel is not registered	Proceed to the Step 3 of "To register the TV channels manually" on this page.
To exit the menu	Press the MENU/OK button.

For details of "SETUP TOUR", see page 8.

To register the TV channels manually (MANUAL in the EDIT menu)

You can register the TV channels into the TV's channel list manually.

1 Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.



3 Choose the channel which you want to register.

4 Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

5 Press the ► button to choose an appropriate sound system.
For details, see "SOUND SYSTEM" on page 14.

6 Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

7 Repeat step 5 until your desired TV channel appears.

If the reception is poor	Press the blue or yellow button to fine tune the TV channel.
If noisy sound is heard	Press the ► button to choose an appropriate sound system.

8 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

To edit the channel list (PR LIST) (MOVE and DELETE in the EDIT menu)

You can edit the TV channel list as you like.
Note: After this operation, other channel's PR numbers will be changed.

1 Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.



3 Choose the channel which you want to change PR number, or delete.

4 Do the following action:

To change the PR number (MOVE)	Press the ► button. Then move it to the PR number you want to use it for the channel. Finally press the ◄ button.
To delete the channel (DELETE)	Press the yellow button.

5 Press the MENU/OK button to exit the menu.

To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like.
You need to find the "CH/CC" number for the TV channel. Find the "CH/CC" number corresponding to the channel number of the TV channel from the attached sheet "CH/CC number list" on page 21.

1 Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

3 Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

4 Press the green button, then press ▲/▼ buttons to choose "CC" or "CH".

5 Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

TV channel presetting (continued)

CH/CC number

When you want to use the INSERT function on page 20, find the CH/CC number corresponding to the channel number of the TV channel from this table.

Channel No.	Country
US	United States, Philippines, etc..
CCIR	Middle East, Southeast Asia, etc..
OIRT	Eastern Europe, Russia, Vietnam, etc..
AUSTRALIA	Australia, etc..

Channel

CH	US	CCIR	OIRT	AUSTRALIA
CH 02	US-2	E2	R1	AU-0
CH 03	US-3	E3		AU-1
CH 04	US-4	E4	R2	AU-2
CH 05	US-5	E5	R6	AU-6
CH 06	US-6	E6	R7	AU-7
CH 07	US-7	E7	R8	AU-8
CH 08	US-8	E8	R9	AU-9
CH 09	US-9	E9		
CH 10	US-10	E10	R10	AU-10
CH 11	US-11	E11	R11	AU-11
CH 12	US-12	E12	R12	
CH 13	US-13			
CH 14	US-14, W+29			
CH 15	US-15, W+30			
CH 16	US-16, W+31			
CH 17	US-17, W+32			
CH 18	US-18, W+33			
CH 19	US-19, W+34			
CH 20	US-20, W+35			
CH 21	US-21, W+36	E21		
CH 22	US-22, W+37	E22		
CH 23	US-23, W+38	E23		
CH 24	US-24, W+39	E24		
CH 25	US-25, W+40	E25		
CH 26	US-26, W+41	E26		
CH 27	US-27, W+42	E27		
CH 28	US-28, W+43	E28		
CH 29	US-29, W+44	E29		
CH 30	US-30, W+45	E30		
CH 31	US-31, W+46	E31		
CH 32	US-32, W+47	E32		

CH	US	CCIR	OIRT	AUSTRALIA
CH 33	US-33, W+48	E33		
CH 34	US-34, W+49	E34		
CH 35	US-35, W+50	E35		
CH 36	US-36, W+51	E36		
CH 37	US-37, W+52	E37		
CH 38	US-38, W+53	E38		
CH 39	US-39, W+54	E39		
CH 40	US-40, W+55	E40		
CH 41	US-41, W+56	E41		
CH 42	US-42, W+57	E42		
CH 43	US-43, W+58	E43		
CH 44	US-44, W+59	E44		
CH 45	US-45, W+60	E45		
CH 46	US-46, W+61	E46		
CH 47	US-47, W+62	E47		
CH 48	US-48, W+63	E48		
CH 49	US-49, W+64	E49		
CH 50	US-50, W+65	E50		
CH 51	US-51, W+66	E51		
CH 52	US-52, W+67	E52		
CH 53	US-53, W+68	E53		
CH 54	US-54, W+69	E54		
CH 55	US-55, W+70	E55		
CH 56	US-56, W+71	E56		
CH 57	US-57, W+72	E57		
CH 58	US-58, W+73	E58		
CH 59	US-59, W+74	E59		
CH 60	US-60, W+75	E60		
CH 61	US-61, W+76	E61		
CH 62	US-62, W+77	E62		
CH 63	US-63, W+78	E63		
CH 64	US-64, W+79	E64		
CH 65	US-65, W+80	E65		
CH 66	US-66, W+81	E66		
CH 67	US-67, W+82	E67		
CH 68	US-68, W+83	E68		
CH 69	US-69, W+84	E69		

CC	US	CCIR	OIRT	AUSTRALIA
CC 01		S-1		AU-5
CC 02		S-2		
CC 03		S-3		
CC 04		S-4		
CC 05		S-5		
CC 06		S-6		AU-5A
CC 07		S-7		
CC 08		S-8		
CC 09		S-9		
CC 10		S-10		
CC 11		S-11		
CC 12		S-12		
CC 13		S-13		
CC 14	A	S-14		
CC 15	B	S-15		
CC 16	C	S-16		
CC 17	D	S-17		

CC	US	CCIR	OIRT	AUSTRALIA
CC 18	E	S-18		
CC 19	F	S-19		
CC 20	G	S-20		
CC 21	H	S-21		
CC 22	I	S-22		
CC 23	J	S-23		
CC 24	K	S-24		
CC 25	L	S-25		
CC 26	M	S-26		
CC 27	N	S-27		
CC 28	O	S-28		
CC 29	P	S-29		
CC 30	Q	S-30		
CC 31	R	S-31		
CC 32	S	S-32		
CC 33	T	S-33		
CC 34	U	S-34		
CC 35	V	S-35		
CC 36	W	S-36		
CC 37	W+1	S-37		
CC 38	W+2	S-38		
CC 39	W+3	S-39		
CC 40	W+4	S-40		
CC 41	W+5	S-41		
CC 42	W+6			
CC 43	W+7			
CC 44	W+8			
CC 45	W+9			
CC 46	W+10			
CC 47	W+11			
CC 48	W+12			
CC 49	W+13			
CC 50	W+14			
CC 51	W+15			
CC 52	W+16			
CC 53	W+17			
CC 54	W+18			
CC 55	W+19			
CC 56	W+20			
CC 57	W+21			
CC 58	W+22			
CC 59	W+23			
CC 60	W+24			
CC 61	W+25			
CC 62	W+26			
CC 63	W+27			
CC 64	W+28			
CC 75		X		
CC 76		Y	R3	
CC 77		Z	R4	AU-3
CC 78		Z+1	R5	
CC 79		Z+2		AU-4
CC 95	A-5			
CC 96	A-4			
CC 97	A-3			
CC 98	A-2			
CC 99	A-1			

Additional preparation

The illustrations shown in this section are for AV-29VS24 and AV-21CS24 only, which are used for explanation purpose. Your TV may not look exactly the same as illustrated.

Before connecting

- Read the manuals provided with the devices for the proper connection.
- Turn off all the devices including the TV.
- Note that connecting cables are not supplied.

Connecting to front video input terminal



Connecting to rear component/video input terminal and output terminal





When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture displays on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 18).

Troubleshooting

If a problem occurs when you are using the TV, check the below troubleshooting guide before calling for repair.

• No picture, no sound	• Deactivate the BLUE BACK function if it is turned on. • Choose the appropriate sound system. Refer to “SOUND SYSTEM” on page 14.
• Snowy picture	• Check the aerial cable and its connection with the TV.
• Stripes appear on the picture	• Interference occurs caused by other devices such as an amplifier, personal computer, or a hair drier. Move such devices away from your TV.
• Double-pictures (ghosting) occur	• Interference occurs caused by signal reflecting from mountains or building. Try to adjust the aerial’s direction or use a better directionality antenna.
• Poor picture	• Choose the appropriate colour system. Refer to “COLOUR SYSTEM” on page 9. • Adjust the COLOUR or BRIGHT setting. Refer to “Adjusting the picture - USER” on page 10.
• White and bright still image look as if it were coloured	• Inevitable phenomenon due to the nature of the picture tube. This is not a malfunction.
• Top of the image from software products or video tape is distorted	• This is due to the condition of the video signal whereby the image was not recorded properly. This is not a malfunction.
• Poor sound	• Adjust the sound frequency properly. Refer to “EQUALIZER” on page 15.
• Stereo or bilingual sound is unclear	• TV channel reception is poor. Change the stereo/ bilingual mode to mono sound (see page 15).
• Cannot operate the remote control	• The batteries may be exhausted. Replace with new batteries (see page 7). • Ensure that you are operating the remote less than seven meters from the front of your TV.
• Cannot operate the menus	• Press TV/VIDEO button to return to TV mode and try operating the menus.
• Cannot operate the front control buttons	• Deactivate the CHILD LOCK function if it is turned on (see page 17).
• TV is turned off suddenly	• This may due to the AUTO SHUT OFF function is activated. Press the POWER button to turn on the TV.
• Colour patches appear at the corner of the screen	• This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker.
• Picture is tilted	• This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt.
• Image takes a short period to be displayed	• Image required time to stabilize before display. This is not a malfunction.
• TV may emitted crackling sound	• This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection.
• Feel a slight electric shock when touching the TV screen	• This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction.

Specifications

TV RF systems

B, G, I, D, K, M

Colour systems

PAL, SECAM, NTSC 3.58 MHz, NTSC 4.43 MHz

Receiving channels

VHF low channel (VL), VHF high channel (VH), UHF channel (U)
Receives cable channels in mid band, super band and hyper band.

External input / output

VIDEO-1:	S-video input*, VIDEO input, AUDIO L/R input
VIDEO-2/COMPONENT:	VIDEO input, AUDIO L/R input, COMPONENT VIDEO ($Y/C_B/C_R$) input (Except for AV-21CS24/AV-21CX14/AV-21YX14)
VIDEO-3:	VIDEO input, AUDIO L/R input (Except for AV-21CS24/AV-21CX14/AV-21YX14)
OUTPUT:	VIDEO output, AUDIO L/R output
Headphone jack:	Stereo mini jack (3.5 mm diameter)

*Except for AV-29LS24/AV-29LX14/AV-25LS24/AV-25LX14/AV-21CS24/AV-21CX14/AV-21DX14/AV-21LX14/AV-21YX14.

****Sound-multiplex systems**

A2 or NICAM (B/G, I, D/K)

****Teletext system**

FLOF (Fastext), WST (World Standard Text)

****Language displayed by teletext**

Please see the table in the description “TEXT LANGUAGE” on page 13.

**Depends on the models, STEREO/I•II function for the Sound-multiplex systems or Teletext function may not be available. Please confirm with the chart on page 3.

Design and specifications subject to change without notice.

VICTOR COMPANY OF JAPAN, LIMITED

© 2004 VICTOR COMPANY OF JAPAN, LIMITED



EQUALIZER • CINEMA SURROUND • COMPONENT INPUT

Contents

Knowing your TV's features 3
Remote control buttons and basic functions 4
TV buttons and functions 6
Setting up your TV 7
Basic setting for picture 9
Advanced setting for picture 11
Original features for picture 12
Basic setting for sound 14
Advanced setting for sound 15
Favorite channel and video setting 16
Customized setting 17
TV channel presetting 19
Additional preparation 22
Troubleshooting 23
Specifications ..... Back cover

INSTRUCTIONS

GGT0050-001C-H

5/25/04, 1:33 PM

for buying this JVC colour television.
your new TV, please read this manual thoroughly before you begin.

NOT
TURE.
THE
F THIS TV.

f the TV.
lugging the

the TV of

hnician. Do

areful with it
d, wipe it
cleaner or

7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

WARNING: <AV-2134YE/AV-2134WE/AV-2153WE/AV-2154WE only> A REMOVABLE PLASTIC COVER IS FIXED TO THE TELEVISION'S FRONT AUDIO/VIDEO CONNECTOR. TO PREVENT THIS COVER FROM BEING ACCIDENTALLY SWALLOWED BY BABIES OR CHILDREN, REMOVE IT FROM THE TELEVISION AND STORE IT IN A SAFE PLACE. IF THE COVER IS SWALLOWED SEEK THE ADVICE OF A DOCTOR IMMEDIATELY.

es

ou can view two different sources (e.g. TV programme and VCR sources) at the same me.
ou can view teletext programmes which are broadcasted by some TV channels. Teletext rogramme is an information in text form.
ou can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 r NICAM Sound-multiplex system.
ou can register up to four favorite channels for quick recall with one press.
V detects the brightness of your room and automatically adjust the picture brightness to a uitable level for a better eye care.
V adjusts the volume automatically to the same level for all TV channels to avoid sudden hange of the volume when selecting different TV channel.

ons

his instruction manual may not be available for your TV.
w and check the functions that are equipped for your TV's model number. The at the rear of your TV. When you press a button concerned to a function that is t does not work and the logo "Ø" appears on the screen. For a function that is t is not displayed in the menu.

	AV-2984VE AV-2983VE	AV-2584VE AV-2184VE AV-2583VE	AV-2183VE	AV-2174VE	AV-2954WE AV-2953WE	AV-2554LE AV-2154LE AV-2553LE AV-2144LE AV-25LS24	AV-2154CE	AV-2154WE AV-2153WE	AV-2934WE	AV-2934LE	AV-2534LE	AV-2134WE	AV-2134YE	AV-29LS24
	○	○	○	–	○	○	○	○	–	–	–	–	–	○
	–	–	–	–	–	–	–	–	–	–	–	–	○	–
	○	○	○	○	○	–	–	○	○	–	–	○	–	–
	○	○	○	○	–	–	–	–	–	–	–	–	–	–
	○	–	–	–	○	–	–	–	○	○	–	–	–	○
	○	○	○	○	○	○	–	○	○	○	○	○	–	○

5/25/04, 1:33 PM

nd basic functions

e.
ction.

olume.
o terminal number, stereo/bilingual broadcast system

R list.
splay the PR list.
e a channel, then press the MENU/OK button.
the PR list. The channels set to favorite channels are

digits programme number, press -/--, then press the

l with one touch.
egister.
until “RETURN PLUS PROGRAMMED!” appears.
button until “RETURN PLUS CANCELED!” appears.
nel, if you have not set or have cancelled the Return



continued)

	Top menu	2nd menu	Location	3rd menu	Location
MENU	INPUT	EXT. INPUT	P.18	–	–
		DISPLAY	P.18	–	–
	PICTURE * If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER.	PICTURE MODE	P.9	–	–
		PICTURE SETTING	P.10	–	–
		WHITE BALANCE	P.10	–	–
		PICTURE FEATURES	–	VNR	P.17
				FAVORITE CH SETTING	P.16
				VIDEO SETTING	P.16
				COLOUR SYSTEM	P.9
				PICTURE BOOSTER	P.10
				COMPRESS (16:9)	P.11
				PICTURE TILT	P.11
	SOUND * If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER.	STEREO/I•II	P.15	–	–
		AI VOLUME	P.15	–	–
		SOUND MODE	P.14	–	–
		EQUALIZER	P.15	–	–
		BALANCE	P.14	–	–
		SOUND TURBO	P.14	–	–
		CINEMA SURROUND	P.15	–	–
	FEATURES	OFF TIMER	P.17	–	–
		CHILD LOCK	P.17	–	–
		AI ECO SENSOR	P.11	–	–
		PIP	–	PIP,SUB INPUT,SWAP	P.12
	INSTALL	AUTO PROGRAM	P.19	–	–
		EDIT/MANUAL	P.19	DELETE, MOVE, MANUAL,INSERT	P.19-P.20
		LANGUAGE	P.17	LANGUAGE	P.17
		BLUE BACK	P.11	–	–
		AUTO SHUTOFF	P.18	–	–
		VIDEO-2 SETTING	P.18	–	–
		AI ECO DISPLAY	P.11	–	–
		TEXT LANGUAGE	P.13	TEXT LANGUAGE	P.13
	EXIT	–	–	–	–

lote

e MENU, DISPLAY or choose nu.

button ❸ to he next page functions.

–

e MENU/OK to exit from .

–

his manual,

5/25/04, 1:33 PM

No.	Button/terminal	Description	Page
❶	⏻ (main power)	Press to turn on or turn off the TV's main power.	–
❷	POWER lamp	Indicate the TV is being turned on or off. No colour: TV's main power is being turned off. Red : TV's main power is being turned on. Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds.	–
❸	ECO sensor		–
❹	Remote control sensor		–
❺	TV/ VIDEO	Press to select TV or video mode.	–
❻	VOLUME -/+	Press to adjust the volume level.	–
❼	CHANNEL -/+	Press to select the desired channel.	–
❽	MENU	Press to display the menu.	–
❾	IN (VIDEO-3)	Video and audio input jacks for VIDEO-3 mode.	22
	IN (VIDEO-2)	Video and audio input jacks for VIDEO-2 mode.	22
❿	🎧	Headphone jack.	22
⓫	⊤	Aerial socket.	7
⓬	OUTPUT	Video and audio output jacks. (The component video signal cannot be output.)	22
⓭	COMPONENT (VIDEO-2) INPUT	Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 18).	22
⓮	VIDEO-1 INPUT	Video or S-VIDEO, and audio input jacks for VIDEO-1 mode	7
⓯	TIMER lamp	Indicate the OFF TIMER function is being turned on or off. No colour: The OFF TIMER function is being turned off. Orange : The OFF TIMER function is being turned on.	–

How to operate the menus with the TV button

TV button	Work as same as the button on the remote control unit	Note
MENU	MENU/OK button	To display main menu and exit menu after finish setting.
CHANNEL -/+	▼/▲ button	To select menu function.
VOLUME -/+	◄/► button	To adjust the desired function.

ecting.

aerial

lied)

ur VCR
onnect the
the TV
udio

erial

e as your

2 Connecting the compatible main plug to the AC outlet.



3 Inserting batteries into the remote control.

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

CAUTION:

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- It the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



4 Turn on the TV by pressing the main power button.

JVC logo appears on the screen.

5/25/04, 1:33 PM

utton, then operate the TV menu by following the steps as below:



- TV will start searching for the channels.

  To stop AUTO PROGRAM, press MENU/OK button.

- Press the red button to cancel the SETUP TOUR RESTART function.
  If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.



- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 19.

T LANGUAGE, and AUTO PROGRAM functions to make the initial settings.

tial settings, press the TV/VIDEO button to exit from initial settings.
ed language as follow:

picture is

S menu

e table

	System
	PAL
	PAL
	PAL
	SECAM
	NTSC
	SECAM
	PAL
	PAL
	PAL
	PAL
	PAL
	PAL
	SECAM

PICTURE MODE

You can choose the desired picture setting with one-touch. Press the PICTURE MODE button to select a setting.

SOFT	Softens contrast and sharpness.
BRIGHT	Heightens contrast and sharpness.
STANDARD	Standard picture setting.
USER	You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*)

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

5/25/04, 1:33 PM

WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.

✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

NORMAL	Normal white balance.
COOL	Bluish white.
WARM	Reddish white.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

htness of

screen.
choose

E TILT)
netic force.
ES menu
.
RES menu

2 Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.

✳ (MENU) ➡ (PICTURE menu) ➡ (PICTURE FEATURES menu) ➡ (COMPRESS (16:9))

BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.

✳ (MENU) ➡ (INSTALL menu) ➡ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 4:02 PM

When VIDEO-2 is set to component, if the input source of main picture is set to VIDEO-2 with component, PIP button is disabled and sub picture can't be displayed.

TELETEXT

You can watch the Teletext broadcast channel with TEXT function.

1 Press the TEXT button to select the desired mode as follows:

→ TV mode → TEXT mode → MIX mode →

2 Press the CHANNEL -/+ buttons, number buttons or colour buttons to select other Teletext pages.

3 Press TEXT or TV/VIDEO button to return to TV mode.

You can also operate the teletext using the following buttons:

(Hold)	Hold a teletext page. The (hold) are displayed at the top left of the screen. To cancel, press (Hold) button again.
(Reveal)	Display the hidden text (e.g. answers to a quiz). To cancel, press (Reveal) button again.
(Size)	Enlarge the teletext display.
(Index)	Return to the index page instantly.
(Cancel)	Watch TV programme while waiting for a teletext page. When the teletext page is found, a page number appears at the upper left of the screen. Press (Cancel) to view the teletext page.
(Sub-page)	Operate the (Sub-page) function. Sub-page numbers are displayed at the left of the screen. To cancel sub-page function, press (Sub-page) button again.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

TEXT LANGUAGE

You can set the Teletext language group that corresponds to the programmes.
Select TEXT LANGUAGE in the INSTALL menu, then choose the desired language group.

✳(MENU) ➔ (INSTALL menu) ➔ (TEXT LANGUAGE)

GROUP-1	English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish
GROUP-2	Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian
GROUP-3	Polish, German, Estonian, Lettish, Russian, Ukrainian

Depending on the broadcast, the language set may not display properly.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 4:02 PM

ormal

e table

	System
	B/G
	D/K
	I
	B/G
	M
	D/K
	D/K
	B/G
	I
	B/G
	I
	B/G
	B/G

SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE)

USER	You can change this sound setting as you like. Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz). For details, see “EQUALIZER” on page 15.
DYNAMIC	Emphasize on both vocal sound and music.
MUSIC	Emphasize on music effect.
NEWS	Emphasize on vocal sound.

BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (BALANCE)

SOUND TURBO

You can set the sound frequency to emphasize the low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

EQUALIZER

You can adjust the sound frequencies when selecting USER mode in SOUND MODE.

1 Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

2 Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.



3 Select and adjust the desired frequencies.

4 Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.
Select the AI VOLUME in SOUND menu, then choose ON or OFF.
✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 4:02 PM

o setting

4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

1 Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VIDEO SETTING)

2 Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.
✳ (VIDEO SETTING) ➔ (VIDEO STATUS)

3 Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.



4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

✻ (MENU) ➡ (FEATURES menu) ➡ (CHILD LOCK)

OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.



You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

✻ (MENU) ➡ (FEATURES menu) ➡ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

✻ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 4:02 PM

EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (EXT. INPUT)

DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST

Choose a TV channel or a VIDEO terminal.

1 Press the DISPLAY button to display the PR LIST.

2 Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.



To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (DISPLAY)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.



3 Choose the channel which you want to register.

4 Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

5 Press the ► button to choose an appropriate sound system.
For details, see “SOUND SYSTEM” on page 14.

6 Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

7 Repeat step 5 until your desired TV channel appears

If the reception is poor	Press the blue or yellow button to fine tune the TV channel.
If noisy sound is heard	Press the ► button to choose an appropriate sound system.

8 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

6/8/04, 4:02 PM

To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like. You need to find the “CH/CC” number for the TV channel. Find the “CH/CC” number corresponding to the channel number of the TV channel from the attached sheet “CH/CC number list” on page 21.

1 Display the INSTALL menu.
⁕ (MENU) ➔ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

3 Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

4 Press the green button, then press ▲/▼ buttons to choose “CC” or “CH”.

5 Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

⁕ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

US	CCIR	OIRT	AUSTRALIA
S-33, W+48	E33		
S-34, W+49	E34		
S-35, W+50	E35		
S-36, W+51	E36		
S-37, W+52	E37		
S-38, W+53	E38		
S-39, W+54	E39		
S-40, W+55	E40		
S-41, W+56	E41		
S-42, W+57	E42		
S-43, W+58	E43		
S-44, W+59	E44		
S-45, W+60	E45		
S-46, W+61	E46		
S-47, W+62	E47		
S-48, W+63	E48		
S-49, W+64	E49		
S-50, W+65	E50		
S-51, W+66	E51		
S-52, W+67	E52		
S-53, W+68	E53		
S-54, W+69	E54		
S-55, W+70	E55		
S-56, W+71	E56		
S-57, W+72	E57		
S-58, W+73	E58		
S-59, W+74	E59		
S-60, W+75	E60		
S-61, W+76	E61		
S-62, W+77	E62		
S-63, W+78	E63		
S-64, W+79	E64		
S-65, W+80	E65		
S-66, W+81	E66		
S-67, W+82	E67		
S-68, W+83	E68		
S-69, W+84	E69		

US	CCIR	OIRT	AUSTRALIA
	S-1		AU-5
	S-2		
	S-3		
	S-4		
	S-5		
	S-6		AU-5A
	S-7		
	S-8		
	S-9		
	S-10		
	S-11		
	S-12		
	S-13		
A	S-14		
B	S-15		
C	S-16		
D	S-17		

CC	US	CCIR	OIRT	AUSTRALIA
CC 18	E	S-18		
CC 19	F	S-19		
CC 20	G	S-20		
CC 21	H	S-21		
CC 22	I	S-22		
CC 23	J	S-23		
CC 24	K	S-24		
CC 25	L	S-25		
CC 26	M	S-26		
CC 27	N	S-27		
CC 28	O	S-28		
CC 29	P	S-29		
CC 30	Q	S-30		
CC 31	R	S-31		
CC 32	S	S-32		
CC 33	T	S-33		
CC 34	U	S-34		
CC 35	V	S-35		
CC 36	W	S-36		
CC 37	W+1	S-37		
CC 38	W+2	S-38		
CC 39	W+3	S-39		
CC 40	W+4	S-40		
CC 41	W+5	S-41		
CC 42	W+6			
CC 43	W+7			
CC 44	W+8			
CC 45	W+9			
CC 46	W+10			
CC 47	W+11			
CC 48	W+12			
CC 49	W+13			
CC 50	W+14			
CC 51	W+15			
CC 52	W+16			
CC 53	W+17			
CC 54	W+18			
CC 55	W+19			
CC 56	W+20			
CC 57	W+21			
CC 58	W+22			
CC 59	W+23			
CC 60	W+24			
CC 61	W+25			
CC 62	W+26			
CC 63	W+27			
CC 64	W+28			
CC 75		X		
CC 76		Y	R3	
CC 77		Z	R4	AU-3
CC 78		Z+1	R5	
CC 79		Z+2		AU-4
CC 95	A-5			
CC 96	A-4			
CC 97	A-3			
CC 98	A-2			
CC 99	A-1			

5/25/04, 1:34 PM

Connecting to rear component/video input terminal and output terminal

Rear of TV

AV-2934WE



Rear of TV

AV-2134YE



When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture display on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 18).

• Cannot operate the remote control	• The batteries may be exhausted. Replace with new batteries (see page 7). • Ensure that you are operating the remote less than seven meters from the front of your TV.
• Cannot operate the menus	• Press TV/VIDEO button to return to TV mode and try operating the menus.
• Cannot operate the front control buttons	• Deactivate the CHILD LOCK function if it is turned on (see page 17).
• TV is turned off suddenly	• This may due to the AUTO SHUT OFF function is activated. Press the POWER button to turn on the TV.
• Colour patches appear at the corner of the screen	• This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker.
• Picture is tilted	• This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt.
• Image takes a short period to be displayed	• Image required time to stabilize before display. This is not a malfunction.
• TV may emitted crackling sound	• This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection.
• Feel a slight electric shock when touching the TV screen	• This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction.

5/25/04, 1:34 PM

z

UHF channel (U)
nd and hyper band.

O input, AUDIO L/R input
L/R input, COMPONENT VIDEO (Y/C_B/C_R) input (Except for AV-2134YE/

L/R input (Except for AV-2134YE/AV-2154CE.)
O L/R output
mm diameter)
4LE/AV-2554LE/AV-25LS24/AV-2134YE/AV-2144LE/AV-2154CE/AV-2154LE.

ANGUAGE" on page 13.
Sound-multiplex systems may not be available. Please confirm with the chart

ut notice.

JVC
VICTOR COMPANY OF JAPAN, LIMITED

0504-FLE-JMT

5/25/04, 1:34 PM